

INSTRUCTIONS FOR TAKING SAMPLES TO BE ANALYZED FOR CHEMICALS

1. Decide where you're going to sample from (example: kitchen sink (cold), hosebib at well, etc.).
2. Run the cold water 2-3 minutes, then fill all bottles in the prescribed order (bottles with no preservative will be filled first, the bottles with a preservative will be filled next).
3. Turn water off. Go to the bacteria sampling instructions, if you're sampling for bacteria.

All chemical analysis samples are accepted Monday through Thursday, and Friday with prior approval. Friday acceptance of samples may incur weekend surcharges.